

Using a diagram of your window is the best way to ensure proper measurements every time. While each window is different, and square and plum can never be assured, these points will almost always guarantee the most accurate measurements for whatever treatment is chosen.

